



## Product data

Size: RS	Approx. torque (Nm)	SW (tool width) (mm)	Aperture (Ø mm)	For cable/pipe outer diameter (mm)
25	1	2.5	25-26	0+3.6-12
31	1	2.5	31-32	0+4-17
43	4	4	43-45	0+4-23
50	4	4	50-52	0+8-30
68	4	4	68-70	0+26-48
75	4	4	75-77	0+24-54
100	4	4	100-102	0+48-70
125	7	5	125-127	0+66-98
150	7	5	150-152	93-119
175	7	5	175-177	119-145
200	7	5	200-203	138-170
225	17	10	225-228	151-181
250	17	10	250-253	176-206
300	17	13	300-303	206-236
350	17	13	350-353	244-286
400	17	13	400-403	294-336
450	35	17	450-453	344-386
500	35	17	500-503	394-436
550	35	17	550-553	444-486
600	35	17	600-603	494-536
644	35	17	644-647	538-580


RS 25-200




RS 225-644




# Installation




1 Make or verify an aperture.




2 Clean the aperture.




3 The cable/pipe shall go straight and centered through the sleeve.




4 Not acceptable.




5 Not acceptable.




6 Adapt the RS seal by peeling off layers from the halves until you reach the gap seen in step 7. The number of layers may not differ by more than one between the halves.




7 Achieve a 0-1.0 mm gap between the two halves when held against the cable/pipe.




8 Fold out the tabs if any (RS 225-644).




9 Lubricate the inside and the outside sealing surfaces with Roxtec Lubricant.



10 Insert the halves into the sleeve.




11a Tighten the bolts crosswise in small steps to firm compression.




11b


## Check compression



Excess lubricant shall be visible after compression.




The rubber shall expand over the front fittings.




Rubber layers shall bulge outwards, if any.

## Disassembly




Release the compression by loosening the screws alternately.




Remove the RS seal.

## Reinstallation



Clean the sleeve.



Continue the reinstallation from step 6.

## Note

- Wait 24 hours or longer after installation before exposing the cables/pipes to strain or pressure.
- Cables shall go straight through the frame.
- Amendments to these installation instructions are available on [www.roxtec.com](http://www.roxtec.com).

## DISCLAIMER

The Roxtec cable entry sealing system ("the Roxtec system") is a modular-based system of sealing products consisting of different components. Each and every one of the components is necessary for the best performance of the Roxtec system. The Roxtec system has been certified to resist a number of different hazards. Any such certification, and the ability of the Roxtec system to resist such hazards, is dependent on all components that are installed as a part of the Roxtec system. Thus, the certification is not valid and does not apply unless all components installed as part of the Roxtec system are manufactured by or under license from Roxtec ("authorized manufacturer"). Roxtec gives no performance guarantee with respect to the Roxtec system, unless (I) all components installed as part of the Roxtec system are manufactured by an authorized manufacturer and (II) the purchaser is in compliance with (a), and (b), below.

- (a) During storage, the Roxtec system or part thereof, shall be kept indoors in its original packaging at room temperature.
- (b) Installation shall be carried out in accordance with Roxtec installation instructions in effect from time to time.

The product information provided by Roxtec does not release the purchaser of the Roxtec system, or part thereof, from the obligation to independently determine the suitability of the products for the intended process, installation and/or use.

Roxtec gives no guarantee for the Roxtec system or any part thereof and assumes no liability for any loss or damage whatsoever, whether direct, indirect, consequential, loss of profit or otherwise, occurred or caused by the Roxtec systems or installations containing components not manufactured by an authorized manufacturer and/or occurred or caused by the use of the Roxtec system in a manner or for an application other than for which the Roxtec system was designed or intended.

Roxtec expressly excludes any implied warranties of merchantability and fitness for a particular purpose and all other express or implied representations and warranties provided by statute or common law. User determines suitability of the Roxtec system for intended use and assumes all risk and liability in connection therewith. In no event shall Roxtec be liable for indirect, consequential, punitive, special, exemplary or incidental damages or losses."



Roxtec International AB  
Box 540, 371 23 Karlskrona, SWEDEN  
PHONE +46 455 36 67 00, FAX +46 455 820 12  
EMAIL [info@roxtec.com](mailto:info@roxtec.com), [www.roxtec.com](http://www.roxtec.com)